



When using telescoping antenna for FM or TV reception, connect metal straps as shown.




When using telescoping antenna for UHF reception, connect metal straps as shown.


Cable Connections




- For an FM or TV 75-ohm cable:



- For an FM or TV 300-ohm cable:



If both FM/TV and UHF are on external antenna, connect straps as shown above.



For a UHF 75-ohm cable: